

gaiety  
coloured  
clear

**PYREX**

*Regd. Trade Mark*

oven

JAMES A JOBLING & CO LTD  
Wear Glass Works  
Sunderland

# TABLEWARE

two patterns  
three colours

coronet in red or green



wild bryony in charcoal



2100 cup 3/-

The handle is an integral part and can't knock off



2101 saucer 2/-

Gay patterns on pearly-white surface  
—easy to wash up



2105 soup bowl 4/3

Newest shape—use it for soup,  
sweet, cereals



gaiety casseroles



Gaiety casseroles in tomorrow's most exciting glass, pearly white inside . . . irresistibly beautiful colours and patterns outside . . . Snowflake or daisy pattern in white on pink or blue; or in black on yellow

Deep dish 25/- Shallow dish 21/-

With candle-warmer stand 39/-  
and 35/-



round casserole

S2184 2 pt. casserole 16/-

With serving stand, base in pearly glass with black snowflake motif. Clear Pyrex lid



gravyboat and stand

2155/2156 gravyboat & stand 12/6

Snowflake or daisy pattern  
White daisy pattern on pink  
Black snowflake pattern on yellow  
White snowflake pattern on blue



round casserole

S2184 2 pt. casserole 10/-

Base in pearly white glass with black snowflake motif. Clear Pyrex lid



serving dish

2185 8 oz. dish 4/3

8 oz. dish for individual servings.  
Base in pearly white glass with black snowflake motif. Clear Pyrex lid

2102 plate 6½" 2/6

2103 plate 8½" 4/-

2104 plate 10" 5/3



## Gift set 1-C

12/-

1 only 1 pt. casserole  
1 only 1 pt. pudding basin  
1 only 1 pt. flan dish

1041 5/-  
1041 2/-  
1041 4/-

## Gift set 4-C

35/-

1 only 2 pt. casserole  
Family general purpose  
dish  
1 only muffin dish  
1 only flat dish  
1 only oblong pie dish  
1 only pudding basin

1045 8/-  
231 7/-  
268 6/-  
231 5/-  
1148 5/-  
1032 2/-

## Gift set 5B, R, Y or G

The set 30/-

Set of three casseroles in  
bright blue, red, yellow or  
green glass, with coloured  
lids and clear Pyrex  
base. 1—1041, 1—1045, 1—1049

## Gift set 2-C

15/-

1 only 1 pt. casserole  
1 only 1 pt. pudding basin  
1 only 1 pt. flan dish

1041 5/-  
1041 2/-  
1041 4/-

## Gift set 3-C

25/-

1 only fruit bowl  
1 only 1 pt. casserole  
1 only muffin dish  
1 only cake mould

1060 5/-  
1041 10/-  
230 8/-  
1111 5/-



## rolling pin

10/-

The perfect pastry-making tool  
with cold water or crushed ice

## tumbler



1 pt. with red  
or yellow plastic  
holder  
14 5/-

without holder  
12 2.9



## mixer

19 13/-

For whisking,  
separating,  
blending,  
mixing — you'll  
use it for so  
many jobs

instant  
coffee jug

21 27/-


Capacity, 2 pt.  
With gleaming  
stand and candle  
warmer. Packed  
in colourful gift  
box.

## coffee maker

22 50/-

Capacity, 1.5 pt.

The ultimate  
coffee maker gift  
it's fine, well  
constructed stand  
and 1.5 pt.  
coffee maker.




## carafe

23 9/-


Novel kinds of  
drinks — fruit  
juices — make  
in clear Pyrex  
with yellow or  
white decoration




round easy-grip casserole  
1040 1 pt. 3/3 1041 1 pt. 5/6  
1045 2 qt. 8/- 1049 3 pt. 10/-




mixing bowl  
201 2 pt. 4.9 302 2 pt. 7/-  
303 4 pts. 9/-




oblong pie-dish  
1141 1 pt. 4/- 1144 1 pt. 5/3  
1147 2 qt. 7/-  
Use it for oven-steamed fruit and chops



oval platter  
212 12" x 8" 5/6 213 13" x 9" 7/6




fruit bowl and dishes  
1400 12 pt. 5/9 1481 1 quart 1/9




pie funnel  
12 2.4

Smooth, tapered, easy to wash —  
keep your own light, healthy and  
handsome.



measuring  
jug  
18 2 pt. 4.9 20 1 pt. 6/3

Measuring liquids — hot or cold —  
preparing feeding formulae



gravyboat and stand  
200 gravyboat 4/6 211 stand 2/3  
New shape and such a good price!  
No sharp edges, smooth, sleek — after  
Complete with stand



sauceboat and stand  
1429 sauceboat 4/9 1430 stand 2/6  
1332 sauceboat 3/6 1526 stand 2/3



roasting/entrée dish  
233 11.7" x 8" x 2" 7/3

Roast brood, casserole, roast meat, fish, game

1000 17-piece set  
for four people

4 plates 10" 2.7 342

4 plates 8" 2.2 13/- 285

4 plates 6" 1.5 10/- 187

1 plate 10" 5.4 132

1 casserole 1.8" 8/- 1045

1 roaster 10" 4.7 1429

1 roaster 8" 4.7 1429

1 stand 10" 2.4 1.9 1020

Complete £2.18.9

Complete £4.7.9

Complete £6.3.3

Complete £12.13.6

Complete £16.3.3

Complete £20.3.3

Complete £24.3.3

Complete £28.3.3

Complete £32.3.3

Complete £36.3.3

Complete £40.3.3

Complete £44.3.3

Complete £48.3.3

Complete £52.3.3

Complete £56.3.3

Complete £60.3.3

Complete £64.3.3

Complete £68.3.3

Complete £72.3.3

Complete £76.3.3

Complete £80.3.3

Complete £84.3.3

Complete £88.3.3

Complete £92.3.3

Complete £96.3.3

Complete £100.3.3

Complete £104.3.3

Complete £108.3.3

Complete £112.3.3

Complete £116.3.3

Complete £120.3.3

Complete £124.3.3

Complete £128.3.3

Complete £132.3.3

Complete £136.3.3

Complete £140.3.3

Complete £144.3.3

Complete £148.3.3

Complete £152.3.3

Complete £156.3.3

Complete £160.3.3

Complete £164.3.3

Complete £168.3.3

Complete £172.3.3

Complete £176.3.3

Complete £180.3.3

Complete £184.3.3

Complete £188.3.3

Complete £192.3.3

Complete £196.3.3

Complete £200.3.3

Complete £204.3.3

Complete £208.3.3

Complete £212.3.3

Complete £216.3.3

Complete £220.3.3

Complete £224.3.3

Complete £228.3.3

Complete £232.3.3

Complete £236.3.3

Complete £240.3.3

Complete £244.3.3

Complete £248.3.3

Complete £252.3.3

Complete £256.3.3

Complete £260.3.3

Complete £264.3.3

Complete £268.3.3

Complete £272.3.3

Complete £276.3.3

Complete £280.3.3

Complete £284.3.3

Complete £288.3.3

Complete £292.3.3

Complete £296.3.3

Complete £298.3.3

Complete £302.3.3

Complete £306.3.3

Complete £310.3.3

Complete £314.3.3

Complete £318.3.3

Complete £322.3.3

Complete £326.3.3

Complete £328.3.3

Complete £332.3.3

Complete £336.3.3

Complete £340.3.3

Complete £344.3.3

Complete £348.3.3

Complete £352.3.3

Complete £356.3.3

Complete £360.3.3

Complete £364.3.3

Complete £368.3.3

Complete £372.3.3

Complete £376.3.3

Complete £380.3.3

Complete £384.3.3

Complete £388.3.3

Complete £392.3.3

Complete £396.3.3

Complete £400.3.3

Complete £404.3.3

Complete £408.3.3

Complete £412.3.3

Complete £416.3.3

Complete £420.3.3

Complete £424.3.3

Complete £428.3.3

Complete £432.3.3

Complete £436.3.3

Complete £438.3.3

Complete £442.3.3

Complete £446.3.3

Complete £450.3.3

Complete £454.3.3

Complete £458.3.3

Complete £462.3.3

Complete £466.3.3

Complete £470.3.3

Complete £474.3.3

Complete £478.3.3

Complete £482.3.3

Complete £486.3.3

Complete £490.3.3

Complete £494.3.3

Complete £498.3.3

Complete £502.3.3

Complete £506.3.3

Complete £510.3.3

Complete £514.3.3

Complete £518.3.3

Complete £522.3.3

Complete £526.3.3

Complete £530.3.3

Complete £534.3.3

Complete £538.3.3

Complete £542.3.3

Complete £546.3.3

Complete £550.3.3

Complete £554.3.3

Complete £558.3.3

Complete £562.3.3

Complete £566.3.3

Complete £570.3.3

Complete £574.3.3

Complete £578.3.3

Complete £582.3.3

Complete £586.3.3

Complete £590.3.3

Complete £594.3.3

Complete £598.3.3

Complete £602.3.3

Complete £606.3.3

Complete £610.3.3

Complete £614.3.3

Complete £618.3.3

Complete £622.3.3

Complete £626.3.3

Complete £630.3.3

Complete £634.3.3

Complete £638.3.3

Complete £642.3.3

Complete £646.3.3

Complete £650.3.3

Complete £654.3.3

Complete £658.3.3

Complete £662.3.3

Complete £666.3.3

Complete £670.3.3

Complete £674.3.3

Complete £678.3.3

Complete £682.3.3

Complete £686.3.3

Complete £690.3.3

Complete £694.3.3

Complete £698.3.3

Complete £702.3.3

Complete £706.3.3

Complete £710.3.3

Complete £714.3.3

Complete £718.3.3

Complete £722.3.3

Complete £726.3.3

Complete £728.3.3

Complete £732.3.3

Complete £736.3.3

Complete £740.3.3

Complete £744.3.3

Complete £748.3.3

Complete £752.3.3

**Follow these few simple rules and your  
Pyrex will last a lifetime—  
and always look as good as new**

- 1 Don't use it on the hob or over a naked flame
- 2 Don't suddenly cool a hot dish by putting it down on a very cold or wet surface or by pouring cold water into it
- 3 Don't let the food bake dry in Pyrex; always grease Pyrex dishes
- 4 Don't use strong abrasives on Pyrex—a nylon scourer is ideal. If you do scorch the food, soak the dish for half an hour in a table spoon of baking soda dissolved in a quart of warm water. Then wash as usual. For slight stains, a damp cloth and a little salt are enough

\* Use of coloured Pyrex in pressure cookers is to be avoided. Coloured Pyrex glass has the same remarkable heat-resisting properties as clear Pyrex glass but the colour itself may be affected when cooking certain food, especially cabbages, turnips and dried fruit

Just to be sure, please use clear Pyrex in your pressure cooker



Buy only original Pyrex. Look for this hall-mark on every piece

We guarantee to replace any article damaged by oven-heat during the first 12 months

Prices are strictly net to the public and include purchase tax

# COLOURED PYREX IN RED, YELLOW, BLUE OR GREEN



## mixing bowl sets


300 Harlequin set of 2 pt. blue,  
3 pt. red, 4 pt. yellow bowls, in the  
gay scarlet and yellow gift pack. Or  
all red, blue, yellow, or green

The set 29/6



## fruit set 1400 27/9

1 large bowl and 6 small dishes in  
the lovely scarlet and yellow gift pack



## oval platter

312 small 8/- 313 large 10/9



## plates

382 7½ inch 3/-

385 9" 4/9 387 10" 5/9



## soup plates

389 9" diameter 5/9

For serving and keeping your soup  
really hot; and making your table a  
most cheerful sight



## soup bowls

390 ½ pint 4/6

Does double-duty for cereals or soup



## sauceboat and stand

1629 sauceboat 6/9

1630 stand 3/9



## gravyboat and stand

320 gravyboat 6/3

321 stand 3/3

## round easy-grip casserole



1040 8 ounce 4/6 1041 1 pint 7/3

1045 2 pint 10/6 1049 3 pint 13/-

Coloured bases and clear PYREX lids



## carnival mixing bowl set 2170 35/-

4 pt. turquoise blue, 3 pt. pink,  
2 pt. yellow, coloured outside,  
white inside. In a beautiful pack